

# DRC

## 1. Clock Rules (C Rules)

### 1.1 C1

When all clocks are at their off state as defined with the `add_clocks` command, all clock inputs (including sets and resets) of scan and non-scan cells must be at their off state. For non-scan cell violations, the tool converts these to TIEX.

注意：不要定义是异步时钟，要定义成同步时钟。