

===== ssn =====

1. ijtag streaming interface

设置streaming interface为ijtag, 即可以通过JTAG接口来输入scan test pattern

此时edt 和 occ slow clock都来自于ssn host, 由tck分频而来。scan_en=0时, occ切换到fast clock进行正常的at-speed capture操作。<code tcl> set_ssn_options -streaming_interface ijtag </code> 下面是波形截图 {{:edastudy:tessent:pasted:20231106-221125.png}}

2. retarget 2 tile

retarget时, 建议总是打开on_chip_compare_enable。这样会在ssn host里面保存scan sticky结果, 方便jtag读取结果。<code tcl> set_core_instance_parameters -module gps_baseband_rtl1_tessent_ssn_scan_host_1

```
-parameter_values { on_chip_compare_enable on on_chip_compare_group 1 }
```

</code>

2.1 use ssn_bus streaming interface

下图是同时retarget 2个gps模块的波形图, 其内部edt同时工作, 并且几乎是同时停, 没有带宽浪费。{{:edastudy:tessent:pasted:20231106-223433.png}}

下图是说edt clk & shift clk这些是从bus_clk分频而来的。{{:edastudy:tessent:pasted:20231106-224131.png}}

2.2 use ijtag streaming interface

下图是仅使用ijtag接口来传scan pattern。从图中看出bus_clk没有时钟。regartet 2个GPS模块, 2个edt同时停, 没有带宽浪费。{{:edastudy:tessent:pasted:20231106-225037.png}}

3. retarget 3 tile

3.1 ssn bus scan pattern

下图是3个tile一起retarget的情况, 一个process core, 2个gps core, 从图中看出scan_en下降的时间不一样。{{:edastudy:tessent:pasted:20231106-230004.png}}

放大, 看edt_clk & shift clock 细节, 比较明显的是process core的edt clk给得慢。gps core给得快 (几乎是2个process edt clk的时间, 3个gps edt clk。而且 process edt channel宽度更窄一些, 说明算法已经在尽量平衡带宽, 又保证ssn bus带宽不浪费。{{:edastudy:tessent:pasted:20231106-230352.png}}

3.2 ijtag scan pattern

retarget 3 tile, streaming interface只使用ijtag {{:edastudy:tessent:pasted:20231106-230933.png}}

retarget 3 tile, streaming interface只使用ijtag, 放大
{{:edastudy:tessent:pasted:20231106-231056.png}}

4. DefaultChildConfiguration

```
<code> set spec [create_dft_specification -sri_sib_list ssn] read_config_data -in $spec -from_string {
SSN {
```

```
DefaultChildConfiguration {
    bus_register_reset :off;
}
Datapath(1) {
    output_bus_width : 16;
    Pipeline(1) { //operates at 1/4 rate
    }
    BusFrequencyDivider(1) {
        frequency_ratio : 4;
    }
    Pipeline(2) { //operates at full rate
    }
}
```

```
}} </code>
```

5. extrace_icl

如果抽icl时遇到说ssn path没有定义，可以使用如下方式定义一下再抽取icl

```
<code tcl> SETUP> add_icl_ssn_datapaths {1} SETUP> set_icl_ssn_datapath_ports -name 1 -
clock_inputs ssn_bus_clock
-bus_data_inputs ssn_bus_data_in[15:0] -bus_data_outputs ssn_bus_data_out[15:0] SETUP>
extract_icl </code>
```

6. clock arch?

{{:edastudy:tessent:pasted:20240606-171655.png?nolink}}

{{:edastudy:tessent:pasted:20240606-171709.png?nolink}}

