

eco commands

用于在insertion添加eco逻辑进去。

不建议使用process_top_module_connections命令，这个命令是站在顶层，然后穿层次到模块里面的信号的连接，会自动开port[]连接，不是一个好的tile flow[]

1. create_instance

2. create_module

3. create_net

4. create_port

5. create_pin

6. intercept_connection

这个命令好用，用于在某个位置添加MUX或and或加buffer取反这些都很方便而且还可以抽取ICL

```
intercept_connection node -cell_function_name function_name  
[-technology dft_cell_selection_name]  
[-input2 input2_source] [-select select_source]  
[-leaf_instance_prefix prefix_name]  
[-only_when_has_functional_source]
```

7. create_connections

8. delete_connections

```
delete_connections obj_spec [-within] [-silent]
```

如果不带-within[] 是删除obj instance outside外部的连线，带-within，就是删除obj inside内部的连线。

9. move_connections

```
move_connections -from obj_spec1 -to obj_spec2 [-net_name net_name] [-silent]
```

If the object within obj_spec1 a PIN:

The command moves the net connected to this pin to the pin specified in obj_spec2 and the pin in obj_spec1 is left unconnected.

10. get_dft_cell

命令

```
get_dft_cell clock_buffer -cell_selection_name tech_name_1
```

结果

```
{my_buff}
```

命令

```
get_dft_cell and -input 4
```

结果

```
{and_4}
```

eco feed through

思路：

为了ECO修改后模块尽量可重用，即模块内部修改一模一样，可以提前先放一批cell到模块里面，然后再用ECO进行连线。

[connect.tar.gz](#)

get_nets

```
get_nets [name_patterns] [-below_instances instance_objects]
[-of_pins pin_objects | -of_ports port_objects | -of_gate_pins
gate_pin_objects | -of_pseudo_ports pseudo_port_objects] [-bundle]
[-hierarchical] [-filter attribute_equation] [-regexp] [-nocase] [-silent]
```

get_nets [name_patterns] 获得net名为pattern的net

get_nets -of_pins xxxpin 获取net跟pin相对应的net net名与pin名名字一样

如果想获取pin 外面连线名，可用get_fanout -stop_on net

